

## PORTAFLOW-C How to install the loader software for PC

When you install the loader software downloaded from our homepage, follow the installation procedure below.

Address: <http://www.fic-net.jp/eng/products/flowmeter/top.html>

### 1 . When you download the loader software for the first time,

Please have the CD-ROM enclosed with the product.

Procedure 1 Install the Windows Installer 3.1.  
(For the PC which has been installed, this procedure is not required.)  
Install this software from the CD-ROM.

Procedure 2 Install the Microsoft .NET FrameWork 2.0.  
Install this software from the CD-ROM.

Procedure 3 Install the USBExpress  
Install this software from the CD-ROM.

Procedure 4 Connect the PORTAFLOW-C and the PC via USB cables.  
Recognize the device and install the driver.

Procedure 5 Install the downloaded loader software.

### 2 . When you have already installed the previous version of loader software,

Procedure 1 Uninstall the previous version of loader software [PORTAFLOW-C].  
For uninstalling, selects "control panel" – "add/ delete application" from Windows,  
click Alter and Delete button.

Procedure 2 Install the downloaded loader software.

#### [Caution]

For the installation detail, refer to PORTAFLOW C PC LOADER SOFTWARE  
INSTRUCTION MANUAL.(INF-TN5A0415-E)